

# USING THE *Vista Del Mar* SPA

1. Upon arrival to Vista Del Mar, if the power to the spa is not on, turn it on.
2. When the spa is first actuated, it will go into Priming mode, indicated by “PR” on the display.
  - 2.1. The Priming mode will last for less than 5 minutes (press “Warm” or “Cool” to skip Priming Mode) and then the spa will begin to take temperature readings, followed by the heater test cycle.
3. To display the set temperature, press the “Warm” or “Cool” pad once.
4. Set the desired temperature and put spa into “Standard” Mode by pressing “Warm” and “Light” so that it shows “ST”. (This will heat tub at the rate of 4-6 degrees per hour).
  - 4.1. The last measured spa temperature displayed is current only when the pump has been running for at least 2 minutes.
5. Upon reaching the desired temperature put spa into “Economy” mode by pressing “Warm” and “Light” until it shows “EC”
6. Upon departure from Vista Del Mar, set desired temperature to 80 degrees and put into “Sleep” Mode;
  - 6.1. Sleep mode is engaged by holding “Warm” and “Light” until it shows “SL”

Note: If cycle is not in F2 mode, please change by pressing “Warm” and “Jets” and then press “Warm” to adjust to F2 and then “Jets” to exit

**IMPORTANT: PLEASE COVER THE SPA WHEN IT IS NOT IN USE!**